

# TO DO LIST

## BEFORE YOUR COUNTERTOP TEMPLATE

1		All preexisting countertops must be cleaned off prior to template date. Items should be removed from under the sink and inside top level of cabinets.
2		All base cabinets, support panels, drawers, etc. must be completely and properly installed: permanently set, level, flush, and secured to the wall and floor.
3		All end panels, front door, handles, finish caps, and trim pieces must be in place before template.
4		<b>Any leveling, structural repair, plumbing, or electrical work is the responsibility of the homeowner.</b> The Master's Touch Stoneworks is not licensed to perform any such actions.
5		All new or existing sinks, faucets, soap dispensers, push buttons, cooktops, stoves, etc. that shall be installed must be onsite or in place at the time of template.
6		Parking must be provided but customer on template and installation date. Homes must be completely accessible.
7		Failure to meet any of these conditions may result in an additional trip charge and delay of installation. Footage and additional deviations may result in price adjustment.